

Suzuki Vinson 500 Snorkel High Performance Air Intake

Congratulations on selecting the Diamond G Racing Suzuki Vinson 500 Snorkel High Performance Air Intake.

Tools

*** Flat Head Screwdriver**

Removal and Installation

Remove seat. Loosen clamp from base of stock snorkel intake. Remove plastic inserts holding snorkel by pushing center of insert forward. Remove stock snorkel.

You are now ready to install your new high performance snorkel intake. Install new snorkel into rubber boot on top of air box first. You may need to remove the air box lid to ease installation. Align snorkel with hole in plastic that you removed the original insert. Reinstall insert. Make sure snorkel is not in a bind and fits without kinking rubber inlet hose. Tighten clamp.

Jetting depends on elevation. However, we highly recommend the DynoJet jetting kit or equivalent (Moose, etc.). For elevations less than 2000 feet, with an aftermarket exhaust and K&N filter, install needle in third clip with a 220 DJ main jet. With a stock exhaust, use a 190 DJ main jet and install the needle in the third position. If you ride at higher elevations and need jetting help, please feel free to give us a call.

Thank you for purchasing this Diamond G Racing Snorkel. For technical assistance, please call (714) 299-3865. Please ride safe!

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.